Photolux Übersicht Treibereinstellung aller gängiger Epson Drucker

Drucker / Papier	Photo R1800	Photo R2400	Photo R2880	Photo R3000	Stylus Pro 3800	Stylus Pro 3880	Stylus Pro 4800	Stylus Pro 4880
PHO Prem. Matt 120	Archival Matte Paper	Archival Matte Paper	Archival Matte Paper	Archival Matte Paper	Archival Matte Paper	Archival Matte Paper	Archival Matte Paper	Archival Matte Paper
PHO Prem: Matt 165	Archival Matte Paper	Archival Matte Paper	Archival Matte Paper	Archival Matte Paper	Archival Matte Paper	Archival Matte Paper	Archival Matte Paper	Archival Matte Paper
PHO Prem Matt 180 Duo	Archival Matte Paper	Archival Matte Paper	Archival Matte Paper	Archival Matte Paper	Archival Matte Paper	Archival Matte Paper	Archival Matte Paper	Archival Matte Paper
PHO Prof. Matt 230	Archival Matte Paper	Archival Matte Paper	Archival Matte Paper	Archival Matte Paper	Archival Matte Paper	Archival Matte Paper	Archival Matte Paper	Archival Matte Paper
PHO Studio Portrait 240	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper
PHO Studio Pearl 255 ct/wt	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper
PHO Studio DUO 270	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper
PHO FineArt Velvet 270	Velvet Fine Art Paper	Velvet Fine Art Paper	Velvet Fine Art Paper	Velvet Fine Art Paper	Velvet Fine Art Paper	Velvet Fine Art Paper	Velvet Fine Art Paper	Velvet Fine Art Paper
PHO Studio Silver 282	Premium Glossy PhotoPaper	Premium Glossy PhotoPaper	Premium Glossy PhotoPaper	Premium Glossy PhotoPaper	Premium Glossy PhotoPaper	Premium Glossy PhotoPaper	Premium Glossy PhotoPaper	Premium Glossy PhotoPaper
PHO Studio Pro2 300	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper	Premium Semigloss Photo Paper	Premium Semigloss Photo Paper

Drucker / Papier	Stylus Pro 4900	Stylus Pro 7600/9600	Stylus Pro 7800/9800	Stylus Pro 7880/9880	Stylus Pro 7890/7890	Stylus Pro 7900/9900	Stylus Pro 11880
PHO Prem. Matt 120	Archival Matte Paper	Archival Matte Paper	Archival Matte Paper	Archival Matte Paper	Archival Matte Paper	Archival Matte Paper	Archival Matte Paper
PHO Prem: Matt 165	Archival Matte Paper	Archival Matte Paper	Archival Matte Paper	Archival Matte Paper	Archival Matte Paper	Archival Matte Paper	Archival Matte Paper
PHO Prem Matt 180 Duo	Archival Matte Paper	Archival Matte Paper	Archival Matte Paper	Archival Matte Paper	Archival Matte Paper	Archival Matte Paper	Archival Matte Paper
PHO Prof. Matt 230	Archival Matte Paper	Archival Matte Paper	Archival Matte Paper	Archival Matte Paper	Archival Matte Paper	Archival Matte Paper	Archival Matte Paper
PHO Studio Portrait 240	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper
PHO Studio Pearl 255 ct/wt	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper
PHO Studio DUO 270	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper
PHO FineArt Velvet 270	Velvet Fine Art Paper	Velvet Fine Art Paper	Velvet Fine Art Paper	Velvet Fine Art Paper	Velvet Fine Art Paper	Velvet Fine Art Paper	Velvet Fine Art Paper
PHO Studio Silver 282	Premium Glossy PhotoPaper	Premium Glossy PhotoPaper	Premium Glossy PhotoPaper	Premium Glossy PhotoPaper	Premium Glossy PhotoPaper	Premium Glossy PhotoPaper	Premium Glossy PhotoPaper
PHO Studio Pro2 300	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper	Premium Semigloss PhotoPaper

© 2011 Photolux GmbH